

Assembling instruction for Jeannie de Lange Vinyl dolls with connectors

Before using the connectors, think about filling all vinyl parts except the body firmly with your filling material!

Please leave some space for the connector parts!

Warning: don't overstretch the elastic, it may break!

Attaching the head

Step 1: Unhook the steel hook from the plastic tube by using the green tool.

Separate the elastic and the lower plastic disc (with the bigger hole) from the elastic.

Step 2: Put the metal disc and the plastic disc (with the smaller hole) together with the elastic inside the vinyl head by using a pliers. Watch out that the elastic part doesn't drop inside the vinyl head.

Step 3: Put the tube and the plastic disc (with the bigger hole) over the green tool. Insert now the tool together with disc and tube from the bottom of the torso through the neck hole.



Step 4: Turn the vinyl torso upside down and hitch the metal hook with the green tool. Pull the metal hook together with the elastic through the tube carefully by fixing the tube with a finger through an arm hole and hook it into the end of the tube.

Remove the tool and the head is fixed.



Attaching the arms

Step 1: Unhook the steel hook from the elastic at one side of the tube.

Put the part with the elastic inside an arm by using pliers. The bow of the elastic should be out of the arm.

Put the part with the metal hook and the metal- and plastic disc into the other arm by using pliers.

Watch out that the metal hook doesn't drop inside the vinyl arm.



Step 2: Put the plastic tube over the green tool. Insert the tool together with the tube from one armhole to the other. Carefully draw the elastic from one arm through the tube inside the body, to the other side of the body and hook the metal hook from the other arm into the elastic. A third hand may be helpful. Remove the tool. Now the arms are fixed.

Attaching the Legs:

Step 1: unhook the metal hook with the green tool. Remove the bigger (40mm) metal disc from the elastic. Insert the part with metal and cardboard disc and elastic into one of the legs.

Attach the big (40mm) metal disc over the elastic loop outside the leg. The bigger metal disc must cover the whole in the vinyl leg. Otherwise the plastic tube will slip into the leg.

Insert the other part with smaller metal disc and cardboard disc into the other leg. The 40mm metal disc has to be outside the leg, to cover the leg whole also.

Step 2: Now put the bevelled plastic tube over the green tool and insert it through the body-leg wholes from one side to the other.

Hook the tool into the elastic loop and pull it to the other side, to hook in the other leg. A third hand is helpful at this time. Opening up the metal hook a little makes the work easier.

Now it's the last chance to fill up the body with your filling material.

After filling fix the legs into the groove and the assembling is finished.

